For evaporator pans



Features

Sizes 3.8 L and 20 L

Advantages

- Agrizone exclusivity
- 100 % biodegradable
- Phosphate-free
- Acid detergent
- Effectively cleans evaporator pans in an envirionmentally friendly way
- Can also be used to clean limestone on stainless steel

Manual of use

For regular and frequent washing:

- Mix 0.5 to 2 L Acericlean per 100 L of water depending on degree of dirt. Always put water before adding product
- Heat the solution without boiling to increase efficiency.
- You can briefly soak for small cleanups but for the most stubborn residues soaking for 6 to 24 hours is recommended.
- Rinse thoroughly the pan with drinking water before reuse.
- You could use a nylon brush if necessary for stubborn residues.
- For very dirty evaporator pans you can use from 2 to 4 liters of Acericlean per 100 liters of water.









Complementary products



M to 3XL

077-5760x



001-7824



Glasses

068-9807



8 to 12

052-2858x





